

Location: Queen's University

Responsibility: Principal Investigators (PI), Research Staff, Veterinary Staff

Purpose: The purpose of this Standard Operating Procedure (SOP) is to describe commonly-used manual restraint techniques for rats.

- 1. Introduction and Definitions:** Correct manual restraint is used in order to avoid and/or limit pain and distress to the rat. It is a valuable tool for competently performing several standard procedures such as a general health assessment, blood collection, tissue collection and ear-punching. Additionally, correct restraint aids in
-

V-Hold or Suspender Hold: This hold is commonly used when a firmer restraint is required, such as for oral gavage or two-person IP injections.

Grasp the whole torso, with the index and middle fingers along the sides of the head and the thumb and remaining fingers under the axilla.

Alternatively, circle your thumb and index fingers under the jaw to control the head while the rest of your finger support the chest behind the forelegs. Use your other hand to support the lower body and hold the tail. Both methods restrict head movement while allowing access to the facial area.

The animal's arms can be gently crossed and held closed for additional security.

Applying too much pressure to the head or chest can result in struggling and injury to the animal.

Scruff Hold: This hold is commonly used for subcutaneous injections. At Queen's University we recommend using the Camilla Method for administering injections (if practical). This technique uses a cloth as a simple restraining device and provides the animal with a place to hide which will help it to relax.

Lift the rat from its home cage to a clean, flat surface.

Cover the rat's head and upper body with a cloth. Prevent the animal from advancing forward using the edge of your hand. Use that same hand to form a skin tent. Give the injection with your free hand, bracing its backside if necessary.

Alternatively, with animals that have been handled frequently and are accustomed to injections, the user may be able to bypass the towel method and simply form a skin tent with one hand as the other administers the injection into the scruff or flank of the animal.

http://www.lssu.edu/faculty/jroese/AnimalCare/rat_handling.htm

Torso or Sausage Wrap: This hold is commonly used for IP injections. It can also be used to restrain the animal for SC or IV injections, and blood sampling.

Lift the rat from its home cage to a clean, flat surface where a towel or small drape is laid flat.

Place the cranial 2/3 of the animal on the towel in the lower third of the towel.

Firmly roll the lower third portion of the towel around the rat.

Fold the excess towel back over the animal's body to create a pocket.

Wrap the remaining 2/3 of the towel securely around the rat to immobilize it.

Brace the "sausage" between your forearm and hip with the abdomen facing upwards.

Hold the tail and



University Animal Care Committee Standard Operating Procedure

Document No:
10.20

Subject:
Manual Restraint of Rats



Novel IP restraint technique: This hold was developed for animals that are accustomed to handling. It alleviates stress to the animal, and allows for clear visualization of the needle hub.



Revised: February 28, 2019 / February 22, 2022